

Follow these steps to keep that new floor shining for years to come!

ECO CorFlex

Molecular Industrial Polymers

Tools and materials needed

- Broom or leaf blower (helpful to blow out dirt and leaves)
- Rinse-free Wash & Wax automotive detergent (available at any auto parts store or Home Depot)
- String mop, bucket and wringer
- Microfiber dust mop

Cleaning your newly coated space

- Blow out or sweep loose dust and debris
- Prepare a Wash & Wax cleaning solution
 - (mix 2 oz of Wash & Wax per 1 gallon of warm water)
- Immerse the string mop in the solution and wring out twice.
- Lightly damp mop the coated surface
- Allow the floor to dry - no rinsing is required
- For best results, use a microfiber dust mop to dry the floor after damp mopping



Do not use any other detergents as they tend to leave a soapy residue and may diminish the natural beauty of your floor. These residues will also attract dirt and grime from your car or truck tires.

Tips and cautions

- Use WD-40® to remove sticky deposits such as tar, chewing gum, etc.
- Do not place non-porous, rubber-backed mats (e.g., doormats) on the coated surface as the rubber backing may cause a chemical reaction (discoloration)
- Eco-CorFlex has specialized floor mats available for use under vehicles (including golf carts) to protect your floor from battery acid. Contact us for details.

Once again, thank you and if you have any further questions, please feel free to contact us at 602-795-4178.